


LUOTTAMUKSELLINEN, VAIN SISÄISEEN KÄYTTÖÖN
JOUSITUKSEN PALLONIVELTEN MAKSIMIVÄLYKSET

Ohessa ohjearvot jousituksen pallonivelten maksimivälyksille uusimpien mallien osalta.

Ystävällisin terveisin

TOYOTA AUTO FINLAND OY
Tekninen palvelu


Timo Suutari-Jääskö

LIITTEET

ohjearvot, 1 sivu

JAKELU

Lexus-korjaamopäällikkö
Lexus-varaosapäällikkö
Toyota Baltia
TAF/AS Lexus (Notes)

TIEDOTE 11.Alusta ja voimansiirto: 2001/02

P Taskinen/UH

01.03.01

2 (2)

	FRONT		REAR	
	UPPER	LOWER	UPPER	LOWER
LS430 (UCF30)	No feel of play by hand	Max. Play: 0.4 mm [Push the hub bolt up and down with a force of 294 N (30 kgf)]	No feel of play by hand	No feel of play by hand
LS400 (UCF20)	No feel of play by hand	Max. Play: 0.3 mm [Push up the axle by hand]	No feel of play by hand	No feel of play by hand
GS430, 400, 300 (UZS161, 160, JZS160)	No feel of play by hand	Max. Play: 0.9 mm [Push the hub bolt up and down with a force of 294 N (30 kgf)]	No feel of play by hand	Max. Play: 0.3 mm [Push the hub bolt up and down with a force of 294 N (30 kgf)]
SC430 (UZZ40)	No feel of play by hand	Max. Play: 0.9 mm [Push the hub bolt up and down with a force of 294 N (30 kgf)]	No feel of play by hand	Max. Play: 0.3 mm [Push the hub bolt up and down with a force of 294 N (30 kgf)]
SC400, 300 (UZZ30, JZZ31)	No feel of play by hand	Max. Play: 0.4 mm [Push the hub bolt up and down with a force of 294 N (30 kgf)]	No feel of play by hand	Max. Play: 0.3 mm [Push the hub bolt up and down with a force of 294 N (30 kgf)]
IS300, 200 (JCE10, GXE10)	No feel of play by hand	Max. Play: 0.9 mm [Push the hub bolt up and down with a force of 294 N (30 kgf)]	No feel of play by hand	Max. Play: 0.3 mm [Push the hub bolt up and down with a force of 294 N (30 kgf)]
RX300 (MCU10, 15)	-	No feel of play by hand	-	-
ES300 (MCV20)	-	No feel of play by hand	-	-
LX470 (UZJ100)	Max. Play: 0.5 mm [Push the hub bolt up and down with a force of 294 N (30 kgf)]	Max. Play: 0.5 mm [Push the hub bolt up and down with a force of 294 N (30 kgf)]	-	-