

REASON Mounting of fuselage fairings

EFFECTIVITY PIK-20, PIK-20 B and PIK-20 D all serial numbers

DESCRIPTION For better airflow around the fuselage there can be mounted fairings on the fuselage under and upper side behind the wings.

COMPLIANCE Optional

INSTRUCTIONS The fairings are mounted according to Eiriavion Working Instruction ALK.AS. 1 1979-04-05.  
The fairings are delivered by Eiriavion. Other type of fairings must not be used.

WEIGHT AND BALANCE Weighing must be done after the installation.

APPROVED BY THE  
NATIONAL BOARD OF AVIATION  
IN FINLAND

---